HP Cri Visor

клук

FN



WHE00007 204

RED

Technical Details

HELMET HP

EXTERNAL SHELL: ABS INTERNAL SHELL: HD Polystyrene HEADBAND: Soft PA Nylon headband (fixed to the external shell without metal rivets) SIZE: Universal-adjustable from 51 to 62 cm STANDARD: EN 14052



VISOR HP TRANSPARENT MATERIAL: Polycarbonate WEIGHT: 200 g STANDARD: EN 166 – EN 14458 OPTICAL CLASS: 2



Customization Italian Red Cross. (Other customizations available)

Technology

WHE00007 202

YELLOW

WHE00007 201

WHITE



VENTILATION: Maximum ventilation thanks to the ten air intakes. The air intakes and the internal outflow channels guarantee effective breathability.



LAMP CLIPS: Helmet equipped with strong nylon external lamp carrying clips, made of high intensity resin and frontal antislide insert that are compatible with all headlamps with elastic bands on the market.



REFLECTING STICKERS: Adhesive reflecting stickers for high visibility.



CHINSTRAP EN 14052: Four point chinstrap. The safety release system allows quick fastening and opening of the locking mechanism in conformity with EN 14052. Provided with lateral divider for adjusting the length of the straps.



RING TO HOOK: Fitted with a special loop on the chinstrap which allows the helmet to be connected to the harness.



SANITIZED®: The Sanitized[®] treatment is an antibacterial treatment that acts as an internal deodorant counteracting the development of unpleasant odors. Thanks to its hygienic function, it effectively prevents bacterial proliferation by increasing freshness and comfort of the fabric in contact with skin.



2DRY: This high-tech and maximum comfort fabric dries very quickly, encouraging the expansion and dispersion of moisture to the outside and leaving a pleasant feeling of freshness.



MICROMETRICAL ADJUSTMENT: The micrometrical size regulation mechanism positioned at the rear of the helmet provides quick and precise adjustment, even when wearing gloves.



VISOR ATTACHMENT: Provided with attachment for fitting visors.



EARMUFFS FITTING: Provided with bayonet socket adapter for earmuffs. Compatible with KASK earmuffs.

KASK S.p.A. - Via Firenze, 5 - 24060 Chiuduno (BG) Italy t. +39 035 4427497 - f. +39 035 4427704 - e. info@kask.it

HP Cri Visor

ΚΛ/Κ

EN

Performances

PROTECTION AGAINST TOP IMPACTS	K 5 Kg from 2 m 100 J
PROTECTION AGAINST SIDE, FRONT AND REAR IMPACTS	K 5 Kg from 1 m 50 J
PROTECTION AGAINST THE PENETRATION OF OBJECTS	TOP: 1 Kg from 2,5 m 25 J LAT: 1 Kg from 2 m 20 J
CHIN STRAP RELEASE > 15 kg <25 kg	K
RETENTION SYSTEM EFFECTIVENESS	K



K Standard requirements

Additional Information



GUARANTEE

3 years starting from the purchasing date.

SHELF LIFE

10 years starting from the production date (production date is printed on a label contained on the inside of the helmet). Inspect the helmet regularly to check for any damage! Cuts, abrasions, deformation or changes in colour represent important elements for checking the helmet status.

CLEANING

Clean the helmet only with water, neutral pH soap and a soft, clean cloth. The inner lining should be washed by hand in cold water or in the washing machine (max 30°C - 85°F). Do not use chemical detergent or solvent.

STORAGE

When not in use the helmet should be stored away from direct sunlight or source of heat.

ADHESIVE APPLICATION

Do not apply adhesives, solvents, stickers or paint that do not comply with the manufacturer's specifications. Any alteration or intervention not provided for may impair its protective function.

Accessories



WVI00004 VISOR HP



WAC00003 ADAPTER WITH BAYONET



WPA00002 REPLACEMENT INNER PADDING



UPA00001 WINTER PADDING



WHP00001 EARMUFFS



HELMET BAG